

ULV AUTO FOGGER

The most advanced ULV Fogger for Aerial Disinfection.

- ✓ Dry fog, uniform sub micron size liquid particles.
- ✓ Adjustable flow rates of 1-3 litres per hour.
- ✓ Digital Timer to set fogger on for 1-99 mins.
- ✓ High Speed FHP motor for maximum thrust of spray.
- ✓ Advance thrust design of Air – jet nozzle.
- ✓ Fog thrust of > 50 feet.
- ✓ High portable and can be carried or moved easily.
- ✓ Body and internal parts, those resist corrosion & chemical attack.
- ✓ Cover an area of > 20,000 cubic feet.
- ✓ Sturdy and most durable, maintenance free.



About ULV Auto Fogger:

ULV Auto Fogger generates a fog or mist formed by Ultra Low Volume uniform sub-microns size liquid particles (Dry fog). Liquid formulations can be applied in concentrations of 2-90% and flow rates of 1-3 litres per hour (adjustable) using upgraded Flow control mechanism. A digital timer to set the fogger on for 1-99 minutes makes the entire fogging operation hassle free. Fogger runs on a high speed FHP motor that provides maximum thrust of spray coupled with the advance thrust design of Air-jet Nozzle, the fogger can achieves fog thrust of > 50 feet. The storage tank ranges from 6.5 ltrs (SS316L grade) to 8 Ltrs (HDPE grade) best in industry and can cover an area of > 20000 cubic feet.

Specification	ULV Auto Fogger (HDPE)	ULV Auto Fogger (SS)
Timer Devices	Digital timer (1-99 mins)	
Working Hours Counter	Available Digital	
Particle Size	Uniform Sub Micron	
Liquid Flow rate	1-3 Ltrs/Hr (Adjustable)	
Flow Control Mechanism	Available SS 316	
Nozzle System	SS 316 grade , Air Jet Nozzle (Advance Thrust Design)	
Noise Level	< 88 db@ 1 Meter	
Air Filter	Triple Stage with clamp	
Area Coverage	> 20, 000 Cub Ft	
Motor Speed	24, 000 RPM (approx)	
Power Supply	230 VAC, 50/60Hz.	
Material of Construction	Hardware: SS 304. Strainer , Nipples : SS 316 Tubing's: Silicon grade (FDA & USP Class VI Compliant)	
Dry Weight	7-8 Kgs	
Tank Capacity & MOC	8 Ltrs / HDPE	6.5 ltrs / SS 316L

STERIMAXX INC

"A reliable partner in Sterilization !!!

A/55 Shankesh Bldg, Sanghvi Nagar,
Mira Bhayander Road, Mira Road (East).
Thane 401 107 Maharashtra, INDIA.

Cell: +91 9987 51 4946.

sterimaxx@gmail.com. www.sterimax.com