

# Positive Pressure System (PPS)

We offer inbuilt positive pressure system as well as separate wall mounted system. The minimum positive pressure recommended is 2.5 Pascal as per ISO14644f or prevention of infection. IT is advised to maintain differential positive pressure between OT and adjoining area to prevent outside air entry into OT. It is recommended to maintain Positive Pressure in the OT at all times (operational & Non-operational).

## Standalone Positive Pressure System (PPS)



- ✓ We provide ceiling suspended / window mounted Positive pressure system.
- ✓ It is very easy and quick in installation, compact in size and normal power consumption.
- ✓ It takes the normal oxidized air from ambient and delivers inside room at 25 – 28DegC and also maintains positive pressure inside room to ensure unsterile air does not enter in the room.
- ✓ It consists of pre filter, cooling coil, blower section and HEPA filter. It is connected to condenser unit for normal cooling of ambient air.

**STERIMAXX INC**

*"A reliable partner in Sterilization !!!"*

A/55 Shankesh Bldg, Sanghvi Nagar,  
Mira Bhayander Road, Mira Road (East).  
Thane 401 107 Maharashtra, INDIA.  
Cell: +91 9987 51 4946.

sterimaxx@gmail.com. www.sterimax.com