

Pass Box

Static Pass Box

We offer Static Pass-Box used in Hospital, Pharmaceuticals to transfer Material and helps to maintain class between sterile & non sterile area.

FEATURES:

- ✓ Design acc. to GMP-Guideline easy to clean and to disin-fect
- ✓ Doubled Skin Cabinet with Doors and Toughed Glass
- ✓ Cabinet Fabricated in SS 304/316 Structure
- ✓ SS 304 Hinges and Door Handle
- ✓ Electro Magnetic Interlocking System
- ✓ Pre-Installed White and UV Germicidal Light
- ✓ Sound Level Minimum 65db On Scale
- ✓ Power Supply Single Phase 220V 50 Hz



Scrub Station

We bring forward a wide range of Scrub Stations. The offered product is specially designed to meet the varied requirements of the medical sector. This is manufactured for use in OT complexes to provide surgeons with a convenient sink for pre-OT scrub up. Well-known for features like fine construction, easy installation, reliable operations and durable finish standards, the Surgical Scrub Station is offered in various specifications to our clients as per their application specific requirements.

Single bay two bay, three-bay sink fabricated from heavy gauge type 304 SS, stainless steel & shall have seamless welded construction polished to a satin finish. The cabinet interior shall be sound dead end with a fire resistant material.

The unit shall be designed to be installed on the wall using a mounting carrier from both the sides & can be operated by foot, by a knee by Automation & by the elbow. The scrubs sink shall be provided with a front access panel which is easily removed for access to the water control valves, waste connections, stops & SS pipes.



STERIMAXX INC

"A reliable partner in Sterilization !!!"

A/55 Shankesh Bldg, Sanghvi Nagar,
Mira Bhayander Road, Mira Road (East).
Thane 401 107 Maharashtra, INDIA.
Cell: +91 9987 51 4946.

sterimaxx@gmail.com. www.sterimax.com